

*Continuous Forms Processing
& Mailing Equipment*




SPEDO 9100 / 9200 WEB ASSIST UNIT SPARE PARTS LIST

SPEDO UK LTD, 76 WOOLMER WAY, BORDON, HAMPSHIRE GU35 9QF, UK
TEL: +44 (0) 1420 487442 • FAX: +44 (0) 1420 477827
E-MAIL: spedo@spedouk.com • WEBSITE: www.spedouk.com

INDEX


PAPER FEED PARTS.....	3
MAIN DRIVE COMPARTMENT.....	3
MECHANICAL PARTS.....	4
ELECTRICAL COMPONENT PARTS.....	4

PAPER FEED PARTS



- 1.  SP 06 963
DRIVE ROLLER
ASSEMBLY
- 2.  SP 006 827
ROLLER GUIDE
ASSEMBLY
- 3.  SP 006 998
PRESSURE HEAD
ASSEMBLY
[9200 ONLY]

MAIN DRIVE COMPARTMENT



- 1.  SP 002 133
BEARING
- 2.  SP 006 973
BELT, FLAT, 575
X 20MM
- 3.  SP 006 972
PULLEY, MOTOR



4. SP 006 626
PULLEY, FLAT BELT
IDLER ASSEMBLY



5. SP 001 639
FOOT, 19MM



6. SP 005 804
PULLEY, FLAT BELT
DRIVE



7. SP 006 784
SHAFT, ROLLER
DRIVE, 75MM

MECHANICAL PARTS



1.



SP 002 133
BEARING

2.



SP 006 783
SHAFT, ROLLER
DRIVE, 50MM

ELECTRICAL COMPARTMENT PARTS



1.



SP 004 577
PCB, MOTOR
CONTROL

2.



SP 001 604
SPEED POT

3.



SP 006 994
DRIVE INHIBIT
CABLE
[9200 ONLY]



4. SP 006 993
MAINS INLET CABLE



SP 004 549
EMERGENCY STOP SWITCH



SP 004 829
MOTOR