

*Continuous Forms Processing
& Mailing Equipment*



SPEDO 9400 WEB BUFFER SPARE PARTS LIST

**SPEDO UK LTD, 76 WOOLMER WAY, BORDON, HAMPSHIRE GU35 9QF, UK
TEL: +44 (0) 1420 487442 • FAX: +44 (0) 1420 477827
E-MAIL: spedo@spedouk.com • WEBSITE: www.spedouk.com**

INDEX

ELECTRICAL ASSEMBLY PARTS.....3

CABLES.....4


OPERATOR COMPARTMENT PARTS.....5

END COMPONENT PARTS.....5

INFEEED PARTS.....6

PAPER FEED & SAFETY COVER ASSEMBLY.....7

ELECTRICAL ASSEMBLY PARTS



SP 006 094
SENSOR



SP 006 731
FAN ASSEMBLY



1. SP 006 730
OPERATOR PANEL



2. SP 006 748
CONTROL PANEL



3. SP 005 539
MOTOR, ROLLER
DRIVE SERVO



4. SP 006 732
DRIVER, ROLLER
DRIVE SERVO



5. SP 006 777
DISTRIBUTION BOX
COMPLETE



6. SP 006 734
SENSOR, DANCER BAR
ULTRA SONIC



7. SP 005 653
SWITCH, EMERGENCY
STOP



8. SP 004 460
SWITCH, SAFETY
COVER

CABLES



SP 006 020
ROLLER DRIVE MOTOR
CABLE



SP 006 023
ROLLER DRIVE ENCODER
CABLE



SP 006 018
ROLLER DRIVE I/O CABLE



SP 006 733
SERVO DRIVER POWER
CABLE



SP 006 169
RIBBON CABLE



SP 006 774
9400 E-STOP CABLE



SP 006 740
MAINS SAFETY COVER
SWITCH CABLE



SP 006 735
DANCER BAR ULTRA SONIC
CABLE



SP 006 738
PAPER RUN OUT SENSOR
CABLE



SP 006 737
BUFFER EMPTY SENSOR
CABLE



SP 006 736
BUFFER FULL SENSOR CABLE



SP 006 773
9400 ON/OFF CABLE



SP 006 741
LOGIC SAFETY COVER
SWITCH CABLE

OPERATOR COMPONENT PARTS



- (1) SP 004 644
PILLAR, M24 FOOT
- (2) SP 006 822
NYLON FOOT

SP 006 826
FOOT COMPLETE



SP 006 814
PULLEY, MOTOR DRIVE



3. SP 006 838
BELT, MAIN DRIVE




4. SP 006 816
PULLEY, ROLLER
DRIVE



5. SP 002 133
BEARING

END COMPONENT PARTS



SAFETY COVER COMPONENTS

- (1) SP 006 810
CAM,
SAFETY
COVER
- (2) SP 006 811
SPINDLE,
SAFETY
COVER CAM
- (3) SP 006 812
SPINDLE,
SAFETY
COVER



SP 002 133
BEARING

INFEEED PARTS



SP 006 830 TENSION ROLLER ASSEMBLY

- | | | |
|--|---|--|
| (1) SP 006 785
TUBE,
TENSION
ROLLER | (2) SP 006 820
GUIDE,
TENSION
ROLLER | (3) SP 000 833
SCREW, M4
X 12 BUTTON
HEAD |
| (4) SP 006 819
AXLE,
TENSION
ROLLER | (5) SP 000 048
BEARING | (6) SP 000 958
CIRCLIP,
6MM, E-TYPE |



2. SP 006 823
FREE ROLLER
ASSEMBLY



3. SP 006 780
TENSION ROLLER
GUIDE BAR



4. SP 006 824
GUIDE ROLLER
ASSEMBLY




5. SP 006 827
ROLLER GUIDE
ASSEMBLY



6. SP 005 142
DRAG STRIP

PAPER FEED & SAFETY COVER PARTS



1. SP 006 793
SAFETY COVER



2. SP 001 639
FOOT, 19MM RUBBER




3. SP 006 781
PRESSURE ROLLER
BLOCK



4. SP 006 779
PRESSURE ROLLER
CROSS BAR



5. SP 006 778
MOUNTING CROSS BAR



6. SP 006 825
PAPER GUIDE,
MAGNETIC



SP 006 828
SPRING PLUNGER ASSEMBLY

(1) SP 005 679
DOWEL

(2) SP 000 330
SPRING

(3) SP 006 782
M5 SPRING PLUNGER
BODY



7. SP 006 833
SAFETY COVER STOP
ASSEMBLY

(1) SP 006 818
SAFETY COVER STOP

(2) SP 000 655
GRUB SCREW, M5X16
DOG POINT



8. SP 006 829
DRIVE ROLLER
ASSEMBLY

(1) SP 006 813
DRIVE ROLLER END
CAP

(2) SP 006 790
DRIVE ROLLER TUBE



9. SP 006 831
PRESSURE WHEEL
COMPLETE

(1) SP 006 815
PRESSURE ROLLER
COLLAR

(2) SP 004 703
WASHER, M12
SPECIAL

(3) SP 005 971
BEARING

(4) SP 006 786
PRESSURE ROLLER



10. SP 006 832
PAPER GUIDE
ASSEMBLY

(1) SP 005 065
GUIDE MOUNT

(2) SP 006 805
PAPER GUIDE PLATE

(3) SP 000 318
KNOB, KNURLED
M5X10MM